

# SCOUT USER MANUAL



The luminaire shall be installed by a qualified electrician and wired in accordance with the latess IEE electrical regulations or the national requirements.



### **Installation Instructions**

### **Technical Parameters**

Product name SCOUT
Product code 700
Input Voltage AC 220V
Power 15 - 25W
Power Factor >0.9
Beam Angle 120°

Color temperature SINGLE COLOR

Colour rendering index >80 CRI

Working Environment -40°C to +50°C


Dimensions Ø172x400mm, Ø172x600mm, Ø172x900mm

Net weight 4.2 - 6.7 Kg
Control Mode On/Off, DALI



### **Installation Instructions**

- 1. Unscrew the screws to release the base plate.
- 2. Prepare the mounting location. Pass the cable through the center of the base plate. Attach the base plate to the mounting surface.
- 3. Connect the cable to the junction box.
- 4. Install the luminaire housing on the plastic plate.






## **Installation Instructions**

Example wiring diagram

### **AC220V**





# Overall dimensions Overall dimensions

SCOUT M



SCOUT S

SCOUT L